

# TraffiCloud Start-Up Instructions



## TraffiCloud - For anywhere management

---

TraffiCloud is the easiest way to manage your All Traffic Solutions equipment. The TraffiCloud Web interface leverages the power and convenience of the Internet by combining a simple user interface with a connection to your equipment in the field. There is no software to install and no IT department to involve, yet you'll be able to access all your equipment and information from anywhere.

If you purchased a sign and TraffiCloud subscription, or are participating in a Test Drive or TraffiCloud Trial, you have full access to TraffiCloud to configure the equipment on your account.

Sign in at: <http://portal.traffcloud.com>. New users receive a Welcome email from All Traffic Solutions for login via email address and a temporary password. For getting started and configuration help once you're logged in, go to the TraffiCloud **Help** menu **?** and select **Training Videos** or **Getting Started Guides**.

## TraffiCloud Mobile - For extra convenience

---


If you purchased an Android tablet from us, the TraffiCloud Mobile app has been pre-installed. If you have your own Android device, you can purchase and download the app from the [Google Play Store](#). Just open the app and sign in using your TraffiCloud credentials. Then, scan for your devices and connect to any that are within Bluetooth range (note that only one connection is permitted at a time. The Bluetooth pairing code is "ATS").

## TraffiCloud Sign Manager - For local connections only

---

If you won't be using our TraffiCloud Web or App offerings, here's how to install TraffiCloud Sign Manager to directly connect a PC to the sign:

1. Download and install the software from: <http://c.alltrafficsolutions.com/signmanager>
2. Open TraffiCloud Sign Manager and enter your TraffiCloud user name and password.
3. Plug your sign in via USB-A or pair over Bluetooth using the PIN code ATS. Your sign should appear in the **Detected Devices** box and you can manage it with the application.

 **NOTE:** If the sign does not automatically appear beside **Detected Devices**, download and install the USB drivers from <http://c.alltrafficsolutions.com/usb>. After installing the USB drivers, restart the program to refresh.

For details about using TraffiCloud Sign Manager for Windows, refer to the online user guide. In the application, click **Help > Software User's Manual**.

### Getting help

We are here to help! If you have any concerns while using your ATS products, please feel free to call our customer success specialists at 1-800-366-6602, option 2, or email us at [support@altrafficsolutions.com](mailto:support@altrafficsolutions.com).